W270B

Wheel Loader

Bur 87661531

Use for Service Manual

W270B Wheel Loader Service Manual 87661531

Table of Contents

	Description	Section No.
General		Tab 1
Section Index - General		
Standard Torque Specifications		1001
Fluids and Lubricants		1002
Metric Conversion Chart		1003

Engines	Tab 2
Section Index - Engines	
Engine and Radiator Removal and Installation	2000
Aftercooler	2003

Fuel System	Tab 3
Section Index - Fuel System	
For Fuel System Repair, See the Engine Service Manual	

Electrical	Tab 4
Section Index - Electrical	
Removal and Installation of Starter and Alternator	4001
Electrical Specifications and Troubleshooting	4002
Batteries	4003
Instrument Cluster	4005

W270B Wheel Loader Service Manual 87661531

Table of Contents

Description	Section No.
Steering	Tab 5
Section Index - Steering	
Removal and Installation of Steering Components	5001
Steering Specifications, Pressure Checks, and Troubleshooting	5002
Steering Cylinders	5005
Center Pivot	5006
Auxiliary Steering Motor and Pump	5007
Power Train	Tab 6
Section Index - Power Train	
Removal and Installation of Power Train Components	6001
Transmission Specifications, Pressure Checks, and Troubleshooting	6002
Transmission	6003
Front and Rear Axle	6004
Drive Shafts, Center Bearing, and Universal Joints	6005
Wheels and Tires	6006
Transmission Control Valve	6007
Brakes	Tab 7
Section Index - Brakes	
Removal and Installation of Brake Components	7001
Hydraulic Brake Troubleshooting	7002
Brake Accumulators	7004
Parking Brake	7008
Hydraulics	Tab 8
Section Index - Hydraulics	
Removal and Installation of Hydraulic Components	8001
Hydraulic Specifications, Troubleshooting, and Pressure Checks	8002
Cleaning the Hydraulic System	8003
Hydraulic Pump	8004
Loader Control Valve	8005
Cylinders	8006
Pilot Pressure Accumulator and Ride Control Accumulator	8013
Ride Control Valve	8014

W270B Wheel Loader Service Manual 87661531

Table of Contents

Description	Section No.
Mounted Equipment	Tab 9
Section Index - Mounted Equipment	
Air Conditioning Troubleshooting and System Checks For Systems with HFC-134a Refrigerant	9002
Air Conditioner System Service	9003
Removal and Installation of Air Conditioning and Heater Components	9004
Loader	9006
ROPS Cab and ROPS Canpoy	9007
Cab Glass Installation	9010

In Rear Pocket

Electrical Schematic Foldouts and Hydraulic Schematic Foldout

Please click here and go back to our website.

BUY NOW

Then Instant Download the Complete Manual.

Thank you very much!